

GWP Instructions Self Cling Window Poster Sleeve

Step by Step Guide

- Ensure the glass surface that you will be attaching your poster to is clean.
- Insert your poster into the poster sleeve, ensuring it sits between the two pieces of PVC.
- Place the poster sleeve against your window, ensuring that the static tape is facing towards the window and the poster is in a portrait position.
- To create a vacuum between the poster sleeve and the glass, we recommend applying a small drop of water to the surface.
- Place both of your thumbs centrally on the top strip of static tape and, while applying pressure, slide them outwards to the edges.
- Repeat the process with the second band of static tape.

Note: When applying pressure to the tape you should hear static as the tape adheres to the window.

