

Application Instructions WMP Acrylic Wall Mount Panel Poster Kit

Components included:

4x Phillips head screws, 4x standoffs, 2x acrylic panels (A0 size comes with 6x screws and standoffs)

How to apply

1.

Position the rear panel against the wall and use the existing holes as a template to mark where the holes need to be drilled.



2.

Drill the holes and insert rawl plugs (if necessary).



3.

Push the screws through the bodies of the standoffs (so that they protrude out of the end) and screw them into each hole.



4.

With the rear panel lay on a flat surface, position your poster over it centrally (ensuring that all edges are aligned straight).



5.

Position the front panel over the rear panel and align all edges; taking care not to nudge the poster out of position in the process.



6.

Lift the panels up together and align the holes with the standoffs on the wall – keep the two panels gently pressed together to prevent the poster from moving position.



7.

Insert the thumb screws through both panels into the standoffs, then hand-tighten to secure the panels in place (a second person may be required to assist with this step).



8.

To change your poster; simply untighten the thumb screws, remove and separate the panels, and repeat steps 4 to 7 with your new poster.

