## **FAB1 INSTALLATION GUIDE**

## Step by Step guidance on fitting your FAB1 tension banner in to its frame

1.

Assemble your frame.

Lie your frame on a flat surface and lay banner on top (see picture right).



2.

Fold the material over the plastic strip on the long edge of the banner.





**3**.

Slot the folded material in to the channel.





4

Repeat folding on the top edges and slot in to place.





5.

Repeat on all edges until the banner is tight in the centre.



