




**Satin Chrome Suspended Cable With  
Ceiling To Sign Fixings**



**SUPPLIED:**

2.5m steel cable with fixing plate and sign gripper  
1x 1.5mm Allen key  
1 x 3mm Allen key

You may need:

1 x screw per ceiling fixing  
Rawl plugs  
Drill for ceiling holes  
Screwdriver  
Wire cutters (if you need to shorten the cables)

**INSTALLING CABLES**

Mark out your required ceiling position and drill a hole for your fixing screw.

Unscrew the fixing plate from the ceiling fixing and securely screw it into the ceiling where you made the mark.

You can then screw the ceiling fixing back into the fixing plate and hang the cable down, allowing it to unwind.

Attach your poster holders to the cables, using the satin anodised grippers. Tighten the gripper to the cable using the smaller of the two supplied Allen keys, and tighten the gripper to the poster holder using the larger Allen key.

If you need to shorten the cables, simply pull them down through the gripper further, cut with wire cutters, and adjust the grub screw with an Allen key to create the correct tension.

Remember, the cable is only as strong as your ceiling fixing.