



Cable and Rod Display Fixing Channel Instructions (AH02, AH03)

1. Screw your fixing channel into your ceiling, floor or wall.

2. Fit your fixing cable or rod (e.g. AA4) onto the top of the screw supplied with AH03. Slide the toggle (AH03) into the fixing channel (AH02) via the side opening of the channel.



3. Fit your fixing cable (AA4) onto the top of the screw supplied with AH03.



4. Begin to build your cable kit by adding your chosen panel supports (e.g. AG01S) to the cable.

