


# Cable and Rod Display Fixing Channel Instructions (AH02, AH03)

**1.** Screw your fixing channel (AH02) into your ceiling, floor, or wall.



**2.** Fit your cable and fixings (e.g. AA4) or rod and fixings (e.g. ARG05 and ARG06) onto the top of the screw supplied with the toggle (AH03).

**3.** Slide the toggle into the fixing channel via the side opening of the channel.



**4.** Begin to build your display by adding your chosen panel supports to the cable or rod, then attach your poster panels.

