

# Assembly guide: FG2 & FG3 advertising flags

## 1. To assemble the flag:



**1a.** Take the poles and insert them all together, largest to smallest



**1b.** Loop the bungee cord through the eyelet in the printed flag, and slide the flag pole into the channel at the side of the flag, pulling it nice and tight.



**1c.** Tie the bungee cord off on the bracket at the bottom of the pole.

## 2. To assemble the flag base

**2a. Water base** - For flags above 4.5m in height, you will receive a large water base. All others require a small water base.


- **Large water base** - Take the black plates and place them facing inwards on the top and bottom of the base. Then place the threaded bar through the middle of the black plates. Use a washer and wing nut to secure the base by hand. Alternatively, you can use the locking nut supplied, you will just need a spanner. Finally, fill your base with water or sand, and slide your flag pole over the spigot.



- **Small water base** - Remove the fixing bracket from the bottom of the base, turn the base over and push the fixing bracket into place. Place your flag pole into the fixing bracket and twist until tight.



- **2b. Ground spike** - For the easiest installation, simply hammer your ground spike into soft but stable ground (such as soil or sand) using a mallet, then slide your flag pole over the top.



- **2c. Drive-on base** - Screw the adapter into the fixed spigot base. Attach the fixed spigot to the drive-on base with the countersunk screw. Then place your flagpole onto the fixed spigot.



**Please note:** Designed to withstand a max' wind speed of 18mph; take the flag down in severe weather and at night.