


Application Instructions RHM Wooden Crate Display Stand

Components included:

(You will require a 10mm spanner)



How to assemble

1.

Fix the base feet to the bottom of the support legs (on the same side that the header channels are affixed to) by aligning the x3 holes, inserting bolts via the outer side of the support legs and then adding a washer and nut to each bolt before tightening with a spanner.



2.

Lay one of the leg assemblies flat (with the outer side facing down) and insert x8 bolts through the remaining holes from underneath.

Position each of the x4 crates on the support leg so that the bolts protrude through holes in the sides of the crates – ensuring that the crates are orientated correctly so that the openings face towards the top of the display stand. Then add a washer, nut, and finally a cap nut to each bolt and tighten.

Repeat this step to connect the remaining leg assembly to the other side of the crates.



3.

Attach the header to the display stand by sliding it into the header channels from above.

